

# CLASSIC ARCH ASSEMBLY

ISSUE 0109

SHOULD YOU REQUIRE ANY ADDITIONAL GUIDANCE WITH THE ASSEMBLY OF YOUR ARBOUR PLEASE CONTACT OUR TECHNICAL HELP LINE ON 0844 248 9853.

**Thank you for choosing this arch manufactured by the UK's largest manufacturer of timber garden products. In order to gain the most benefit from it, please note the following:**

- If there are any technical queries with the product, please contact our customer help line on 0844 248 9853 between the hours of 8.30 am and 5.00 pm Monday to Friday.
- Please ensure that you thoroughly check all component parts for quantity and quality before you commence building the product. If there are any missing parts, please contact the help line as shown immediately. The manufacturer cannot be held liable for damaged items once any part of the product has been fitted or altered in any way (e.g. Painted)
- Timber is a natural material. It will shrink and swell as a result of varying moisture content.
- Please keep all plastic bags and small parts away from children in order to reduce the risk of suffocation.
- Check periodically to ensure that the timber remains in good condition and if necessary take corrective action.
- Ensure children are supervised and do not climb on the product. Like any product of this nature the gaps between timbers could trap fingers and therefore care should be taken.



**Important :** Assembly of this arch requires two people.

**Helpful Tip :** use the illustration of the screw/nail shown in each step to help you identify which fixing is required during the assembly of your arch.

## Required Tools : (Not Supplied )



DRILL



HAMMER



TAPE MEASURE




POZI DRIVE SCREWDRIVER



SPIRIT LEVEL

## Fixing Pack Contents (CLAFP) :



60mm Screw x 26

**Please note :** Arch uprights will need to be concreted 600mm into ground. Alternatively, if using post supports, you will be required to trim 600mm off the bottom of each post.

